

WAX WARMER



Digital Water, Wax, Oil Warmer

This elegant water, wax, oil warmer specially design for modern & exclusive beauty salons.

Digiwarm unit operates by constantly maintaining the preset temperature and automatically switches off heating once the preset level is reached.

Digiwarm is micro controller based warmer. There is no need to check manually if the wax is warm or not Hence no more burned wax or any more.

Digiwarm

Digiwarm

WAX WARMER



Digi Warm Wax Warmer - The temperature is controlled by computer which features digital temperature display and quick constant temperature to dissolve wax rapidly. Max temperature is 110C .

- **Operation** - Place enough wax into the wax pot. Press the Power Key to ON the unit.
- **Preset temperature** in four modes is for Water 70 °c ,Oil 80 °c, Wax 105 °c, Honey wax 110c user selectable keys are provided user can select the mode according to requirement of treatment
- **When temperature reaches** it preset temperature, the temperature display show Off and audio beep sound generated after every 3 second interval for five times it means the wax warmer reach up to preset level and unit will On automatically when temperature decreases than the preset value.
- **After dissolving the wax completely**, put the wax pot in to the protective tray . If needed reduce the temperature,
- **This can be used** on the face, neck, hands ,feet, or the body.
- **Leave for 15 minutes**, peel off and finish with a moisturizer.

TECHNICAL SPECIFICATION

Product Name	:	DIGIWARM	
Model No.	:	Wax Warmer	
Physical Characteristics	:	Weight :	800 Gms.
		Height	: 3"
		Width	: 8"
		Depth	: 9.75"
Voltage	:	A/C 220-Volts	50 Hz.
Absorbed Power	:	150 VA	
Complies With	:	IEC 601-1	Classification
Safety Class	:	I	
Type	:		
Operating Temperature	:		10° - 110°
Storage Temperature	:	-10° - 70°	



Read instructions before use.

PHYSICAL CHARACTERISTICS

Weight	:	800 gms.
Height	:	3"
Width	:	8"
Depth	:	9.75"

CAUTION:

- . The wax should be tested before apply on the skin.
- . Don't apply on open wounds or skin diseases.
- . Clean the wax pot after every treatment and do not use The single melted wax on multiple clients.